

Setup Codes for URC 3030 / 3031 / 3032 / 3033 / 3034

Set-Up Codes for TVs

A-Mark 1112
 Abex 1143
 Accuscan 1213
 Admiral 1244, 1334
 Adventura 1212
 Aiko 1243
 Akai 1142, 1231
 Alleron 1412, 1421
 Ambassador 1344
 Americana 1232, 1322
 Anam 1233, 1413
 Anam National 1224
 AOC 1112, 1123, 1142, 1422, 1221
 Archer 1112
 Audiovox 1413, 1112
 Bay Crest 1123, 1334
 Belcor 1123
 Beaumark 1121
 Bell & Howell 1324, 1114, 1244
 Bench Mark 1232, 1123, 1413, 1114
 Bradford 1413
 Brockwood 1123
 Broksonic 1112, 1432, 2112
 Candle 1142, 1231, 1423, 1212
 Capehart 1221
 Carver 1223
 CCE 1431
 Celebrity 1111
 Citizen 1243, 1232, 1231, 1142, 1441, 1423, 1211, 1212
 Clairtone 1422
 Colortyme 1223, 1232, 1411
 Concerto 1231
 Conic 1143
 Contec 1413, 1422, 1332
 Craig 1413
 Crosley 1223
 Crown 1413, 1211
 Curtis Mathes 1342, 1232, 1142, 1444, 1211
 CXC 1413
 Daewoo 1243, 2111, 1123, 1211
 Daytron 1123, 1231
 Dumont 1123, 1121
 Electroband 1111, 1422
 Electrohome 1443, 1322
 Emerson 1432, 2112, 1413, 1412, 1344, 1411, 1441, 1442, 1123, 1211, 1422, 1414, 1144, 1332, 1324
 Encor 1143
 Envision 1142
 Fisher 1324, 1333
 Fujitsu 1412
 Funai 1342, 1412, 1413
 Futuretech 1413
 GE 1213, 1214, 1224, 2111, 1131, 1133, 1442, 1312, 1411, 1141, 1343
 Gibraltar 1142, 1123, 1121
 Goldstar 1231, 1142, 1123, 1411, 1143, 2113, 2114
 Granada 1313, 1323
 Grundy 1412, 1413
 Grunpy 1412, 1413
 Hallmark 1411
 Harley Davidson 1411, 1111, 1413, 1223
 Harman/Kardon 1234
 Harvard 1413, 1233
 Heathkit 1114, 1121, 1243
 Hitachi 1313, 1323, 1231, 1144, 1143
 Ima 1413
 Infinity 1223
 Janeil 1212
 JBL 1223
 JCB 1111
 JVC 1222, 1414, 2121, 2122
 Kamp 1332
 Kawasho 1332
 Kaypani 1221
 Kenwood 1142, 1123
 KLH 1233, 1413
 Kloss Novabeam 1234, 1132
 Kloss 1234, 1132, 1212
 KMC 1143
 KTV 1142, 1413, 1422, 1441, 1211, 1421, 1431
 Lloyds 1432, 1413, 1412
 Logik 1114
 Luxman 1231
 LXI 1324, 1223, 1213, 1411, 1331
 Magnasonic 1412, 1142
 Magnavox 1223, 1311, 1423, 1424, 1142
 Majestic 1114
 Marantz 1223, 1142
 Matsui 1431
 Megatron 1411, 1112, 1313
 MEI 1422
 Memorex 1322, 1324, 1231, 1114, 1411, 1433
 MGA 1322, 1142, 1411
 Midland 1213, 1121, 1214, 1312, 1211, 1143
 Minutz 1131, 1133
 Mitsubishi 1322, 1123, 1411, 1244, 2123
 Motorola 1244, 1224
 MTC 1422, 1232, 1231, 1142, 1123

Multitech 1413, 1431
 NAD 1341, 1331, 1411
 NEC 1142, 1231, 1123
 Nikko 1243, 1411
 NTC 1243
 Okron 1123
 Onwa 1413
 Optimus 1341, 1324, 1433
 Optonica 1244, 1334
 Orion 1432, 2112
 Oritron 1413, 1112
 Panasonic 1433, 1214, 1224, 1223
 PCE 1331, 1232
 Penney 1213, 1232, 1214, 1142, 1123, 1122, 1412, 1131, 1133, 1312, 1331, 1321, 1112, 1211, 1143, 1433, 2114
 Performance 1111
 Philco 1223, 1311, 1142, 1123
 Philips 1223, 1311
 Pilot 1142, 1123, 1211
 Pioneer 1341, 1144
 Portland 1243, 1123, 1211
 Priceclub 1232
 Prism 1214
 Proscan 1213
 Proton 1221, 1411, 1112
 Pulsar 1121
 Pulsar 1123
 Quasar 1433, 1214, 1224
 RadioShack 1334, 1413, 1123, 1211, 1143
 RCA 1213, 1122, 1123, 1141, 1312, 1434, 1343, 1242
 Realistic 1324, 1334, 1231, 1142, 1123, 1413, 1411, 1211, 1143
 Rhapsody 1422, 1421
 Runco 1142, 1121
 Sampo 1221, 1211, 1143
 Samsung 1232, 1231, 1142, 1123, 1411, 1143
 Samsux 1211
 Sanky 1142, 1232, 1211
 Sansui 1142, 1232, 1334
 Sanyo 1324, 1333, 1314
 Scimitsu 1123
 Scotch 1411
 Scott 1432, 1123, 1413, 1411
 Sears 1213, 1324, 1342, 1223, 1231, 1331, 1333, 1411, 1412, 1321, 1314
 Sharp 1244, 1334, 1211
 Shogun 1123
 Signature 2000 1114, 1244
 Signature 1114, 1244
 Simpson 1423, 1424
 Sony 1111, 1113, 1241
 Soundesign 1413, 1423, 1411, 1412
 Spectron 1112
 Squareview 1342
 SSS 1123, 1413
 Starlite 1413
 Supre-Macy 1212
 Supreme 1111
 Sylvania 1223, 1311, 1142
 Symphonic 1342
 Tandy 1244, 1334
 Tatung 1224, 1112
 Technics 1433, 1214
 Technol Ace 1412
 Techwood 1214, 1231, 1112
 Teknika 1243, 1223, 1322, 1123, 1114, 1232, 1413, 1231, 1423, 1412, 1211
 Thomas 1231, 1411
 TMK 1231, 1344, 1411
 Toshiba 1331, 1232, 1321
 Tosonic 1422
 Totevision 1211
 Truetone 1433, 1214, 1224
 Universal 1131, 1133
 Vector Research 1142
 Victor 1222
 Vidikron 1223
 Vidtech 1123, 1411
 Viking 1212
 Wards 1223, 1334, 1311, 1114, 1231, 1142, 1123, 1141, 1411, 1131, 1133, 1124, 1412, 1134, 1343, 1241
 Wellton 1411, 1123
 XR1000 1432, 1413, 1342
 Yamaha 1142, 1123
 York 1142
 Zenith 1121, 1243, 1114
 Zonda 1112

Set-Up Codes for VCRs

Adventura 1111
 Aiko 1413
 Aiwa 1111
 Akai 1141, 1214, 1313, 1224
 American High 1124
 Asha 1411
 Astra 1124, 1411, 1111
 Audiovox 1131
 Avis 1241, 1111
 Beaumark 1411
 Bell & Howell 1311
 Broksonic 1311, 1413, 1341, 1314, 1422, 1424

Calix 1311
 Canon 1124
 Calin 1131, 1132
 Candle 1131, 1413
 Capehart 1114
 Carver 1243
 CCE 1413, 1241
 Citizen 1131, 1413
 Colt 1241
 Colortime 1124, 1223, 1413
 Craig 1411, 1241, 1131, 1212, 1412
 Crosley 1124, 1243
 Curtis Mathes 1124, 1223, 1332, 1141
 Cybernex 1411
 Daewoo 1413, 1114, 1144
 Daytron 1114
 Dynatech 1111
 Electrohome 1131
 Electrophonic 1131
 Emerex 1121, 1122, 1123
 Emerson 1331, 1431, 1413, 1421, 1112, 1341, 1314, 1131, 1111, 1342, 1234, 1422, 1424, 1224, 1143, 1333, 1334, 1244
 Fisher 1311, 1122, 1221, 1232
 Fuji 1124, 1122
 Funai 1111, 1423
 GAB 1241
 Garrard 1111, 1423
 GE 1223, 1332, 1124
 Go Video 1344, 1414, 1411
 Goldstar 1131, 1132
 Gradiente 1111
 Harman/Kardon 1111
 Harwood 1241, 1234
 Harwood 1241, 1234
 Headquarter 1211
 Hi-Q 1212
 Hi Point 1331, 1342, 1314
 Hitachi 1142, 1111, 1312, 1323, 1141
 Jensen 1141, 1233
 JVC 1113, 1233, 1141
 KEC 1413, 1131
 Kenwood 1233, 1113, 1141, 1132
 KLH 1241
 Kodak 1124, 1131
 Lloyd 1111, 1333
 Logik 1241
 LXI 1131
 Magnasonic 1411, 1131, 1413
 Magnavox 1124, 1243, 1133, 1321
 Magnin 1411
 Marantz 1124, 1243
 Marta 1131
 Matsushita 1124
 MEI 1242
 Memorex 1111, 1124, 1311, 1411, 1131, 1213, 1212, 1133, 1211, 1322
 MGA 1143, 1244
 MGN Technology 1411
 Minolta 1142, 1312
 Mitsubishi 1143, 1324, 1224, 1233, 1113
 Motorola 1124, 1213
 Movie Walker 1241
 MTC 1111, 1411
 Multitech 1111, 1241
 NAD 1222
 NEC 1132, 1311, 1134, 1141, 1233, 1113
 Nikko 1131
 Noblex 1411
 Olympus 1124
 Optimus 1213, 1131, 1222, 1311, 1322
 Optonica 1231
 Orion 1331, 1431, 1413, 1422
 Panasonic 1322, 1124, 1343, 1242
 Penney 1124, 1411, 1131, 1142, 1323, 1132, 1134, 1221, 1322
 Pentax 1142, 1312
 Philco 1124
 Philips 1124, 1243
 Pilot 1131
 Pioneer 1222, 1233, 1113
 Portland 1114
 Protec 1241
 Proton 1231
 Pulsar 1133
 Quarter 1211
 Quartz 1211
 Quasar 1322, 1124, 1242
 RadioShack 1111, 1131, 1423
 Randex 1131
 RCA 1223, 1332, 1142, 1312, 1321, 1242, 1313
 Realistic 1111, 1411, 1124, 1131, 1213, 1311, 1212, 1211, 1232, 1231, 1123, 1122, 1121
 Ricoh 1133
 Runco 1133
 Samsung 1411, 1144, 1214
 Sanky 1213, 1133
 Sansui 1141, 1233, 1113
 Sanyo 1311, 1341, 1342, 1314, 1143, 1144
 Scott 1331, 1341, 1342, 1314, 1143, 1144
 Sears 1311, 1131, 1124, 1142, 1312, 1212, 1211, 1221, 1232, 1111
 Sharp 1213, 1231
 Shintom 1241
 Shogun 1411
 Singer 1241
 Signature 1124, 1131
 Sony 1121, 1122, 1123, 1124

Soundesign 1111
 STS 1142, 1312
 Sylvania 1124, 1243, 1143
 Symphonic 1111, 1423
 Tatung 1141
 TEAC 1111, 1141
 Technics 1322, 1124
 Teknika 1111, 1124, 1131
 TMK 1411, 1333
 Toshiba 1143, 1144, 1232, 1342
 Totevision 1411, 1131
 Unitech 1411
 Vector 1144
 Vector Research 1132, 1134
 Victor 1141, 1233
 Vico Concepts 1144, 1134, 1224
 Videosonic 1411
 Wards 1111, 1124, 1142, 1312, 1411, 1212, 1213, 1223, 1332, 1241, 1342, 1321, 1231
 XR 1000 1111, 1241, 1124
 Yamaha 1132
 Zenith 1133, 1122, 1123, 1121

Set-Up Codes for Cable Boxes

ABC 1112, 1114, 1122, 1123, 1131, 1133, 1134, 1142
 American 1233
 Antronix 1212, 1312
 Arbatron 1114, 1134, 1131, 1322
 Archer 1212, 1244, 1312
 Belcor 1232
 Cable Star 1232
 Cabletenna 1212
 Cableview 1212
 Century 1244
 Citizen 1244
 Colour Voice 1221, 1222
 Comtronics Eagle 1224, 1233
 Contec 1143
 Dae Ryung Eagle 1123
 Eastern 1113
 Everquest 1141
 Focus 1341
 Garrard 1244
 GC Electronics 1232, 1312
 Gemini 1141, 1241
 General Instruments 1322, 1311, 1114
 Goldstar 1243, 1224
 Hamlin 1124, 1144, 1223, 1314, 1321
 Hitachi 1131
 Hytex 1122
 Jasco 1244, 1334
 Jerrold 1114, 1322, 1134, 1131, 1141, 1132, 1214
 Memorex 1111
 Movie Time 1234, 1311
 Novaplex 1342
 NSC 1234, 1311, 1241
 Oak 1122, 1143
 Omega 1141
 Panasonic 1211, 1242, 1111
 Paragon 1111
 Philips 1244, 1221, 1222
 Pioneer 1332, 1243, 1213
 Popular Mechanics 1341
 Prism 1132, 1133
 Pulsar 1111
 Quest 1243, 1144
 RCA 1211
 Realistic 1312
 Recoton 1341
 Regal 1314, 1144, 1321
 Regency 1113
 Rembrandt 1131, 1241
 Runco 1111
 Samsung 1243, 1224
 Scientific Atlanta 1123, 1323, 1142, 1121
 Seam 1324
 Sigma 1143
 Signal 1141, 1224
 Signature 1131
 SL Marx 1224
 Sprucer 1211
 Starcom 1114, 1141
 Stargate 1141, 1224
 Starquest 1141
 Sylvania 1112
 Tandy 1313
 Teleview 1224
 Texscan 1112
 Tocom 1132, 1133
 Toshiba 1111
 Tusa 1141
 TV86 1234
 Unika 1244, 1312, 1212
 United Artists 1122
 United Cable 1114
 Universal 1244, 1312, 1212, 1232
 U.S. Electronics 1114, 1322, 1323, 1142, 1123
 Viewstar 1234, 1233, 1313
 Videoway 1333, 1111
 Zenith 1111, 1331, 1231
 Zentek 1341